

announcements: Quantization } NOT tested on Midterm 2.
64 QAM

Performance Analysis of PAM (only channel impairment = AWGN additive white gaussian noise)
starting @ (Slides 15-11)

usually, $T_{\text{symb}} = 1$ to make analysis easier

d = voltage of Txed symbol (the amplitude of Txed signal)

→ for now, we assume the Rxer knows what value d is.

★ matched filter will have same bandwidth/shape as the pulse shaping filter
→ no difference/change to signal, aside from adjusting signal gain.


Best Matched Filter:

$$g_r(t) = k g^*(T_{\text{symb}} - t)$$

any integer multiple of T_{symb} will do! (ok!)

optimizes the Rxed SNR. if only channel impairment is AWGN

Performance Analysis of PAM
starting @ (Slides 15-12)



Q: previously we had decision regions dependent on T_{symb}
does this mean as T_{symb} increases,
our decision region also increases?

↓

Ans: yes, if $T_{\text{syms}} \uparrow$ you can think of it as the Rxer has more time to look at the symbol.


⇒ meaning, the Matched Filter is averaging longer the longer the Matched Filter "looks at" or averages the Rxed signal, the potentially more accurate the Rxer will be in deciding the Rxed Symbol

(longer T_{syms})


⇒ longer time to decide the symbol in time domain

⇒ removes more out-of-band noise in freq. domain)

↳ b/c null $BW = \frac{1}{T_{\text{syms}}}$, as $T_{\text{syms}} \uparrow$ Bandwidth \downarrow)



⇒ Tx pulse shape with null Bandwidth (BW) = $\frac{1}{T_{\text{syms}}}$



⇒ Matched Filter Response with null BW = $\frac{1}{T_{\text{syms}}}$

what's the cost?

⇒ longer delay to Rx the signal! (slower speed)

Criteria	Channels	
	Control	Data
T _{symb}	High	Low
Bit Rate	Low	High
Reliability	High	Low
Bit Error Rate (with Error correction codes)	$10^{-5} \rightarrow 10^{-6}$ (low error)	$10^{-1} \rightarrow 10^{-4}$ (higher error)

★ bit rate = $J \cdot f_{\text{symb}}$



back to PAM Analysis of Symbol Error Probability

inner points have different probability of symbol error : $P_i(e)$
i = inner point

outer points have a separate probability of symbol error : $P_o(e)$
o = outer point

total error = ...

$$P(e) = \frac{\# \text{inner points}}{\text{total \# points}} \cdot P_i(e) + \frac{\# \text{outer points}}{\text{total \# points}} \cdot P_o(e)$$

moving on to QAM Performance Analysis \Rightarrow Correct Symbol Detection

★ PAM discussion was
 on Symbol Error Detection.
 $P(c) = 1 - P(e)$

instead of inner / outer points in PAM,

QAM has Type I \Rightarrow 4 sides (interior) $P_1(c)$
 Type II \Rightarrow 3 sides (edge) $P_2(c)$
 Type III \Rightarrow 2 sides (corner) $P_3(c)$

$$P(e) = 1 - P(c)$$

$$P(c) = \frac{\# \text{Type I}}{\text{total \# points}} \cdot P_1(c) + \frac{\# \text{Type II}}{\text{total \# points}} \cdot P_2(c) + \frac{\# \text{Type III}}{\text{total \# points}} \cdot P_3(c)$$

the difficulty \Rightarrow determining the Decision Boundaries for a QAM constellation.

(break @ 11:13 AM)

(return @ 11:18 AM)

Q: disadvantage of QAM?

Ans: First advantage: better spectral efficiency
better symbol error speeds

now, disadvantage: Rx complexity is more than 2x
compared to PAM
much more sensitive to
amplitude & phase distortion

Discussion of Review Slides @ 11:20 AM

Review

on Tx side { Upsampling + Interpolation Pulse Shaping Filter (@ 11:29 AM)
vs. Polyphase Filter Bank for Interpolation

on Rx side { Anti-Aliasing Filter & Downsampling
vs. Polyphase Filter Bank for Decimation

Communication Channel: Tx \rightarrow Channel \rightarrow Rx

we focus on Baseband Digital Processing
in both Txer & Rxer

Discuss... Midterm Questions @ 11:44 AM

- ① Communications System Tradeoff (Fall 2020 Midterm #2.4)
- ② Symbol Timing Recovery (Spring 2021 Midterm #2.1)