

ECE445M/ECE380L.12

Embedded and Real-Time Systems/ Real-Time Operating Systems

Lecture 4: Semaphores, Deadlocks, Debugging, Testing

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

1

Graduate Projects Ideas

1. Extend the OS with more features
 - Efficient with 20 to 50 threads, multiple periodic/edge-triggered interrupts
 - Multiple cores (real-time scheduling algorithms & implementation)
 - Multiple Mailboxes, FIFOs, advanced communication primitives
 - Path expressions, bankers algorithm,
 - Semaphores with timeout, priority inheritance/ceiling (algorithms & implementation)
2. Make your Lab3 OS portable and port to another platform
 - First implement Lab3 on another architecture (each student does their own)
 - Rewrite OS into two parts: common OS.c (maximize), separate CPU.c per architecture (minimize)
3. Design and test a DMA-base drivers for peripherals
 - eDisk driver, compare and contrast your Lab5 to FAT (one person project)
 - Camera, e.g. LM3S811 http://www.ece.utexas.edu/~valvano/arm/Camera_811.zip (one person project)
4. Advanced robot control algorithms on top of OS
 - Reinforcement learning, Kalman filter based control
 - Computer vision object/lane detection/recognition and lane keeping (self-driving car)
5. Write your own memory management
 - Advanced heap, e.g. using Knuth's Buddy Allocation (one-person project)
 - Use of Memory Protection Unit (MPU) on LaunchPad
 - Virtual memory, paging on a different platform (two or more students)
6. Networking, Internet-of-Things (IoT)
 - Port a lightweight TCP/IP stack onto board (e.g. lwIP using external WiFi module via UART)
 - Robots communicate with each other/base station, control robot remotely (vehicle-to-vehicle / vehicle-to-)
7. Use of Launchpad/OS in other applications
 - Energy harvesting OS with checkpointing for frequent power loss
 - OS safety/security mechanisms

Due end of Feb

Level of complexity depends on size of group

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

2

Semaphores

Edsger Dijkstra,
UT Austin CS 1984-2000

- $P()$ or *wait()*
 - Dutch word *proberen*, to test
 - *probeer te verlagen*, try to decrease
 - **OS_WAIT OSSemPend**
- $V()$ or *signal()*
 - Dutch word *verhogen*, to increase
 - **OS_SIGNAL OSSemPost**

Reference Book, Chapter 4

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

3

Semaphore Meaning


- Counting semaphore
 - Number of elements stored in FIFO
 - Space left in the FIFO
 - Number of printers available
- Binary semaphore (= mutex = flag)
 - Free (1), busy (0)
 - Event occurred (1), not occurred (0)

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

4

Spin-Lock Binary Semaphore



Mutual exclusion

```
bWait(&s);
// access LCD
bSignal(&s);
```

What does the semaphore mean?

What would be a better name for s?

What about atomic?

How do we use this to solve critical sections?


Why is this a good solution for critical sections?

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

5

Spin-Lock Counting Semaphore



What does the semaphore mean?

What about atomic?

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

6

Spin-Lock Semaphores

<pre> OS_Wait ;R0 points to counter LDREX R1, [R0] ; counter SUBS R1, #1 ; counter -1, ITT PL ; ok if >= 0 STREXPL R2,R1,[R0] ; try update CMPPL R2, #0 ; succeed? BNE OS_Wait ; no, try again BX LR </pre> <pre> OS_Signal ; R0 points to counter LDREX R1, [R0] ; counter ADD R1, #1 ; counter + 1 STREX R2,R1,[R0] ; try update CMP R2, #0 ; succeed? BNE OS_Signal ; no, try again BX LR </pre>	<pre> void OS_Wait(long *s) { DisableInterrupts(); while((*s) <= 0) { EnableInterrupts(); DisableInterrupts(); } (*s) = (*s) - 1; EnableInterrupts(); } void OS_Signal(long *s) { long status; status = StartCritical(); (*s) = (*s) + 1; EndCritical(status); } </pre>
---	---

LDREX

Program 4.11

STREX

Cortex-M3/M4F Instruction Set, pg. 50

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

7


Mailbox

MailBox_Send(...)

- **bWait(&BoxFree)**
- Put data into Mailbox
- **bSignal(&DataValid)**

MailBox_Recv(...)

- **bWait(&DataValid)**
- Retrieve data from Mailbox
- **bSignal(&BoxFree)**



What do the semaphores mean?

What are the initial values?

What if we remove **bWait(&BoxFree)** and **bSignal(&BoxFree)**?

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

8

FIFO, Queue, or Pipe

FIFO_Put

- Wait(&DataRoomLeft)**
- Disable Interrupts
- Enter data into Fifo
- Enable Interrupts
- Signal(&DataAvailable)**

FIFO_Get

- Wait(&DataAvailable)**
- Disable Interrupts
- Remove data from Fifo
- Enable Interrupts
- Signal(&DataRoomLeft)**

FIFO_Put

- Wait(&DataRoomLeft)**
- bWait(&Mutex)**
- Enter data into Fifo
- bSignal(&Mutex)**
- Signal(&DataAvailable)**

FIFO_Get

- Wait(&DataAvailable)**
- bWait(&Mutex)**
- Remove data from Fifo
- bSignal(&Mutex)**
- Signal(&DataRoomLeft)**


Lecture 4

What do the semaphores mean?
What if the FIFO never fills?

9

No Background Wait

- Redo Mailbox if **Send** in background
- Redo Fifo if **Put** in background (RX)
- Redo Fifo if **Get** in background (TX)




Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

10

Cooperative Spin-Lock


Cooperative spin-lock



*Could be implemented with
a catch and throw*

Lecture 4

Regular spin-lock



Why would you want a timeout error?
How would you implement timeout?

```

if(OS_Wait(&free,T100ms)){
    // use it
    OS_Signal(&free);
} else {
    // error
}
  
```

11

Cooperative Semaphores

```

void OS_Wait(long *s){
    DisableInterrupts();
    while((*s) <= 0){
        EnableInterrupts();
        OS_Suspend(); ← Let other thread run
        DisableInterrupts();
    }
    (*s) = (*s) - 1;
    EnableInterrupts();
}

void OS_Signal(long *s){
    long status;
    status = StartCritical();
    (*s) = (*s) + 1;
    EndCritical(status);
}
  
```

*Do an experiment of Lab 2 with
and without cooperation*

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

12

Blocking Semaphore (Lab 3)


- Recapture time lost in the spin-lock
 - No spin operation, wakeup only on signal
 - Eliminate wasted time running threads that are not doing work (e.g., waiting)
- Implement **bounded waiting**
 - Once thread calls **Wait** and is not serviced,
 - There are a finite number of threads that will go ahead

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

13

Blocking Semaphore



What does the semaphore mean?
What about atomic?

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

14

Blocking Semaphore (V1)

- All threads exist on circular TCB list (active and blocked)
 - Each semaphore simply has a **Value**
 - No blocked threads if semaphore **Value ≥ 0**
 - e.g., if **Value** is -2, then two threads are blocked
 - No information about which thread has waited longest
 - Add to TCB, a **BlockPt**, of type **Sema4Type**
 - initially, this pointer is **null**
 - **null** means this thread is active and ready to run
 - If blocked, this pointer contains the semaphore address
- New Scheduler
 - Find the next active thread from the TCB list
 - Only run threads with **BlockPt** equal to **null**

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

15

Blocking Semaphore (V1)

OS_Wait(Sema4Type *semaPt)

- 1) Disable interrupts, **I=1**
- 2) Decrement the semaphore counter, **S=S-1**

$$(\text{semaPt} \rightarrow \text{Value}) --;$$
- 3) If the **Value<0** then this thread will be blocked
 specify this thread is blocked to this semaphore

$$\text{RunPt} \rightarrow \text{BlockPt} = \text{semaPt};$$

$$\text{suspend thread};$$
- 4) Enable interrupts, **I=0**

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

16

Blocking Semaphore (V1)

OS_Signal(Sema4Type *semaPt)

- 1) Save I bit, then disable interrupts
- 2) Increment the semaphore Value, $S=S+1$


$$(\text{semaPt}->\text{Value})++;$$
- 3) If $\text{value} \leq 0$ then
 - wake up one thread from the TCB linked list
 (no bounded waiting)
 - search TCBs for thread with $\text{BlockPt} == \text{semaPt}$
 - set the BlockPt of this TCB to null
 - do not suspend the thread that called `os_Signal`
- 4) Restore I bit

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

17

Mutex Example (V1)




Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

18

Mutex Example (V1)




Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

19



Mutex Example (V1)







Lecture 4



J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

20









Blocking Semaphore (V2)

OS_Wait(Sema4Type *semaPt)

- 1) Save the I bit and disable interrupts
- 2) Decrement the semaphore counter, $S=S-1$
$$(\text{semaPt}->\text{Value})--;$$
- 3) If the value < 0 then this thread will be blocked
set the status of this thread to blocked,
specify this thread blocked on this semaphore,
suspend thread
- 4) Restore the I bit

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

29

Blocking Semaphore (V2)



OS_Signal (Sema4Type *semaPt)



- 1) Save I bit, then disable interrupts
- 2) Increment the semaphore counter, $S=S+1$
$$(\text{semaPt}->\text{Value})++;$$
- 3) If the value ≤ 0 then
Wake up one thread from the TCB linked list
Bounded waiting -> the one waiting the longest
Priority -> the one with highest priority
Move TCB of the “wakeup” thread
from the blocked list to the active list
What to do with the thread that called OS_Signal?
Round robin -> do not suspend
Priority -> suspend if wakeup thread is higher priority
- 4) Restore I bit



Lecture 4



J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12



30











Semaphore Applications

- Sequential execution
 - **Run-A** then **Run-B** then **Run-C**
- Rendezvous
- Event trigger
 - **Event-A** and **Event-B**
 - **Event-A** or **Event-B**
- Fork and join
- Readers-Writers Problem

Look at old exams

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

41

Readers-Writers Problem

Reader Threads

1) Execute **ROpen(file)**

2) Read information from **file**

3) Execute **RClose(file)**


Writer Threads

1) Execute **WOpen(file)**

2) Read information from **file**

3) Write information to **file**

4) Execute **WClose(file)**



Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

42

Readers-Writers Problem

ReadCount=0: number of Readers that are open

mutex=1: semaphore controlling access to **ReadCount**

wrt=1: semaphore is true if a writer is allowed access

ROpen

wait(&mutex);

ReadCount++;

if(ReadCount==1) wait(&wrt)

signal(&mutex);

RClose

wait(&mutex);

ReadCount--;

if(ReadCount==0) signal(&wrt)

signal(&mutex);

WOpen

wait(&wrt);

WClose

signal(&wrt);


Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

43

Deadlock

- Conditions
 - Mutual exclusion
 - Hold and wait
 - No preemption of resources
 - Circular waiting



Where is the deadlock?

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12


44

Resource Allocation Graph

```
Thread A
wait(&bOLED); //1
wait(&bSDC); //4
use OLED and SDC
signal(&bSDC);
signal(&bOLED);
```

```
Thread B
wait(&bSDC); //2
wait(&bCAN); //5
use CAN and SDC
signal(&bCAN);
signal(&bSDC);
```

```
Thread C
wait(&bCAN); //3
wait(&bOLED); //6
use CAN and OLED
signal(&bOLED);
signal(&bCAN);
```



Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

45

Deadlock Prevention

- No mutual exclusion
- No hold and wait
 - Ask for all at same time
 - Release all, then ask again for all
- No circular waiting
 - Number all resources
 - Ask for resources in a specific order

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

46

Prevention

- No hold and wait

Thread A wait(&bOLED,&bSDC); use OLED and SDC signal(&bOLED,&bSDC);	Thread B wait(&bSDC,&bCAN); use CAN and SDC signal(&bSDC,&bCAN);	Thread C wait(&bCAN,&bOLED); use CAN and OLED signal(&bCAN,&bOLED);
--	---	--

- No circular wait

Thread A wait(&bOLED); wait(&bSDC); use OLED and SDC signal(&bSDC); signal(&bOLED);	Thread B wait(&bSDC); wait(&bCAN); use CAN and SDC signal(&bCAN); signal(&bSDC);	Thread C wait(&bOLED); wait(&bCAN); use CAN and OLED signal(&bOLED); signal(&bCAN);
--	---	--

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

47

Deadlock Avoidance

- Is there a safe sequence?
- Tell OS current and future needs
 - Request a resource
 - Specify future requests while holding
 - Yes, if there is one safe sequence
- OS can say no, even if available
 - Google search on Banker's Algorithm

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

48

Deadlock Detection

- Add timeouts to semaphore waits
- Detect cycles in resource allocation graph
- Kill threads and recover resources
 - Abort them all, and restart
 - Abort them one at a time until it runs

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12


49

Advanced Topics (Grad Students)

- Bounded waiting
- Time-out
- Deadlock avoidance
 - Banker's algorithm
- Deadlock detection
 - Wait-for-graph
 - Resource allocation graph

Two names for the same thing

Works for single instance resources



Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

50

Testing (1)

- How long do you test?
 - n = number of times T1 interrupts T2
 - m = total number of assembly instructions in T2
 - Run test until n greatly exceeds m
- Think of this corresponding probability question
 - m different cards in a deck
 - Select one card at random, with replacement
 - What is the probability after n selections (with replacement) that a particular card was never selected?
 - Similarly, what is the probability that all cards were selected at least once?

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

51

Testing (2)

Entered 486,736,253 times

```
Rx_Fifo_Get
0 24996444 0x000009B4 4601 MOV r1,r0 ;int RxFifo_Get(rxDataType *datapt){
1 47909851 0x000009B6 481D LDR r0,[pc,#116] ; if(RxPutPt == RxGetPt ){
2 12498221 0x000009B8 6800 LDR r0,[r0,#0x00]
3 71517599 0x000009BA 4A1B LDR r2,[pc,#108]
4 14581259 0x000009BC 6812 LDR r2,[r2,#0x00]
5 11109532 0x000009BE 4290 CMP r0,r2
6 10415182 0x000009C0 D101 BNE 0x000009C6
7 12498220 0x000009C2 2000 MOVS r0,#0x00 ; return(RXFIFOFAIL);
8 4860416 0x000009C4 4770 BX lr ; }
9 694345 0x000009C6 4818 LDR r0,[pc,#96] ; *datapt = *(RxGetPt++);
10 4860416 0x000009C8 6800 LDR r0,[r0,#0x00]
11 1388690 0x000009CA 7800 LDRB r0,[r0,#0x00]
12 694345 0x000009CC 7008 STRB r0,[r1,#0x00]
13 4166071 0x000009CE 4816 LDR r0,[pc,#88]
14 1388690 0x000009D0 6800 LDR r0,[r0,#0x00]
15 2777381 0x000009D2 1C40 ADDS r0,r0,#1
16 1388691 0x000009D4 4A14 LDR r2,[pc,#80]
17 0 0x000009D6 6010 STR r0,[r2,#0x00] FIFO_4C123
18 1388692 0x000009D8 4610 MOV r0,r2
19 1388690 0x000009DA 6802 LDR r2,[r0,#0x00]
20 2777380 0x000009DC 4811 LDR r0,[pc,#68]
21 1388690 0x000009DE 4282 CMP r2,r0 ; if(RxGetPt==&RxFifo[RXFIFOSIZE]
22 0 0x000009E0 D102 BNE 0x000009EA
23 0 0x000009E2 3820 SUBS r0,r0,#0x20 ; RxGetPt = &RxFifo[0];
24 1388691 0x000009E4 4A10 LDR r2,[pc,#64]
25 1388690 0x000009E6 6010 STR r0,[r2,#0x00]
26 2083035 0x000009E8 2001 MOVS r0,#0x01
27 0 0x000009EA E7EA B 0x000009C4 ; return(RXFIFOSUCCESS);}
```

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

52

Performance Measures

- Maximum time running with $I=1$
- Percentage of time it runs with $I=1$
- Latency $t_{action} - t_{trigger}$
- Time jitter δt on periodic tasks

$$T_i - \delta t < t_n - t_{n-1} < T_i + \delta t \quad \text{for all } n$$
- CPU utilization
 - Percentage time running idle task
- Context switch overhead
 - Time to switch tasks


Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

53

Context Switch Time

- Just like the Lab 1 measurement



Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

54

Running with I = 1

```
#define OSCRITICAL_ENTER() { sr = StartCritical(); }
#define OSCRITICAL_EXIT() { EndCritical(sr); }
```

- Record time t_1 when $I=1$

```
#define OSCRITICAL_ENTER() {sr = StartCritical(); t1=OS_Time();}
```

- Record time t_2 when $I=0$ again
- Measure difference

```
#define OSCRITICAL_EXIT() {dt=OS_TimeDifference(OS_Time(),t1);
EndCritical(sr);}
```


- Record maximum and total

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

55

Time Jitter



Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

56

Semaphore Drawbacks

- Shared global variables
 - Can be accessed from anywhere
- No connection between the semaphore and the data being controlled by the semaphore
 - Used both for critical sections (mutual exclusion) and coordination (scheduling)
- No control or guarantee of proper usage


Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

57

Monitors

- Proper use is enforced
- Synchronization attached to the data
- Removes hold and wait
- Threads enter
 - One active at a time



<http://lass.cs.umass.edu/~shenoy/courses/fall08/lectures/Lec10.pdf>

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

58

Monitors

- Lock
 - Only one thread active at a time
 - Must have lock to access condition variables
- One or more condition variables
 - If cannot complete, leave data consistent
 - Threads can sleep inside by releasing lock
 - Wait (acquire or sleep)
 - Signal (if any waiting, wakeup else NOP)
 - Broadcast

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

59

FIFO Monitor

Put(item):

- 1) lock->Acquire();
- 2) put item on queue;
- 3) conditionVar->Signal();
- 4) lock->Release();

Get():

- 1) lock->Acquire();
- 2) while queue is empty
 conditionVar->Wait(lock);
- 3) remove item from queue;
- 4) lock->Release();
- 5) return item;

<http://lass.cs.umass.edu/~shenoy/courses/fall08/lectures/Lec10.pdf>

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

60

Hoare vs. Mesa Monitor

- Signal() switches immediately vs. later

Hoare wait:

```
if(FIFO empty)
    wait(condition)
```

Mesa wait:

```
while(FIFO empty)
    wait(condition)
```


Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

61

Kahn Process Network (KPN)

- Parallel programming model
 - Blocking read
 - Non-blocking writes (never full)
 - Tokens are data (no time stamp)



Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

62

Kahn Process Network (KPN)

- Deterministic
 - Same inputs result in same outputs
 - Independent of scheduler
- Non-blocking writes (never full)
- Monotonic
 - Needs only partial inputs to proceed
 - Works in continuous time

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

63

Kahn Process Network (KPN)

```
void Process3(void){
    long inA, inB, out;
    while(1){
        while(AFifo_Get(&inA)) {};
        while(BFifo_Get(&inB)) {};
        out = compute(inA,inB);
        CFifo_Put(out);
    }
}
```

```
void Process3(void){
    long inA, inB, out;
    while(1){
        if(AFifo_Size()==0){
            while(BFifo_Get(&inB)) {};
            while(AFifo_Get(&inA)) {};
        } else{
            while(AFifo_Get(&inA)) {};
            while(BFifo_Get(&inB)) {};
        }
        out = compute(inA,inB);
        CFifo_Put(out);
    }
}
```

ECE445M/ECE380L.12

64

Kahn Process Network (KPN)

- Strictly bounded?
 - Prove it never fills (undecidable!)
 - Dependent on scheduler
- Termination
 - All processes blocked on input
- Scheduler
 - Needs only partial inputs to proceed
 - Works in real time

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

65

KPN Boundedness

- Try to find a mathematical proof
- Experimentally adjust FIFO size
 - Needs a realistic test environment
 - Profile/histogram DataAvailable for each FIFO
 - Leave the profile in delivered machine
- Dynamically adjust size with malloc/free
- Use blocking write (not a KPN anymore)
- Discard the data

Lecture 4

J. Valvano, A. Gerstlauer
ECE445M/ECE380L.12

66

Summary

- Use the logic analyzer
 - Visualize what is running
- Learn how to use the debugger
 - Breakpoint inside ISR
 - Does not seem to single step into ISR
- What to do after a thread calls Kill?