

EE445M/ECE380L.12

Embedded and Real-Time Systems/ Real-Time Operating Systems

Lecture 3: RTOS, OS Kernel, Threads, Context Switch, Thread Management

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

1

References & Terminology

μ C/OS-III, The Real-Time Kernel, or a High Performance, Scalable, ROMable, Preemptive, Multitasking Kernel for Microprocessors, Microcontrollers & DSPs, by Jean J Labrosse, 2009. (there are several versions, with and without a board, including for TI Stellaris MCUs)

μ C/OS-II: The Real Time Kernel, by Jean J. Labrosse , 2002, ISBN 1-5782-0103-9.



The Definitive Guide to the ARM Cortex-M3 and Cortex-M4 Processors, Third Edition, by Joseph Yiu, 2013, ISBN 0-1240-8082-0.

Embedded Systems: Real Time Operating Systems for ARM Cortex-M Microcontrollers, Jonathan W. Valvano (Ch. 3, 4 & 5)

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

2



Threads and Tasks

```
void Producer(void) {
    uint16_t data;
    while(1) {
        data = ADC_In();
        if(OS_Fifo_Put(data) == 0)
            DataLost++;
    }
}
```

```
void Consumer(void) {
    uint16_t data, average;
    uint32_t sum;
    uint16_t n;
    while(1) {
        sum = 0;
        for(n = 0; n < LENGTH; n++) {
            data = OS_Fifo_Get();
            sum = sum + data;
        }
        average = sum/LENGTH;
        OS_MailBox_Send(average);
    }
}
```

```
void Display(void) {
    uint16_t data, voltage;
    while(1){
        data = OS_MailBox_Recv();
        voltage = 31*data/64;
        LCD_Message(0,"v(mV) =",voltage);
    }
}
```

Lecture 3



J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

5

Multi-Threading / Multi-Tasking

Thread: Same program & data

Task: Independent program & data (= process**)



** More in Lecture 8

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

6

Real-Time Operating System (RTOS)

- Thread management & scheduling
- Thread communication & synchronization
- Time management

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

7

Thread Classification

- Periodic, execution at regular intervals
 - E.g., ADC, DAC, motor control
 - E.g., Check CO levels
- Aperiodic, execution can not be anticipated
 - Execution is frequent
 - E.g., New position detected as wheel turns
- Sporadic, execution can not be anticipated
 - Execution is infrequent
 - E.g., Faults, errors, catastrophes

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

8

Real-Time

- RT threads have deadlines
 - Hard real time
 - Guaranteed bounded latency
 - Firm real time
 - Missed deadline loss of quality
 - Soft real time
 - Delayed response reduces value
 - Not real time
 - Best effort, no deadlines whatsoever

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

9

Thread Scheduler

- Thread management
 - Thread states
- Scheduling algorithm
 - What? (order of threads)
 - Round robin
 - Weighted round robin
 - Priority
 - How? (when to decide)
 - Static
 - Dynamic
 - Deterministic/fixed
 - Why? (when to run)
 - Cooperative
 - Preemptive
- Performance measures
 - Utilization
 - Latency
 - Bandwidth

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

10

Time Management

- System time
- Time stamps
 - When did it occur?
 - Performance measures
- Thread sleeping
 - Yield and wakeup after certain delay
 - Run other tasks instead of busy waiting
- Measurements
 - Input capture period -> wheel RPM
 - Input capture PW -> ultrasonic distance

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

11

Additional OS Requirements

- Run-time configurable, extensible
 - Priority, stack size, fifo size, time slice
- Reliability, certification
 - Medical, transportation, nuclear, military
- Scalable
 - 10 threads versus 200 threads
- ROMable
 - Runs in ROM


Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

12

OS Architecture

- Portability
 - Small kernel
 - Hardware abstraction layer (HAL)
 - Common structure
- Extensibility
 - Hooks



Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

13

OS Kernel

- Basic thread management
 - Maintain thread states
 - Running/ready/waiting
 - Context switch
 - Switch running thread
 - Protection
 - OS kernel from threads
 - Threads from each other


Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

14

Thread or Light-Weight Process

- Execution of a software task
- Has its own registers
- Has its own stack
- Local variables are private
- Threads cooperate for common goal
- Private global variables
 - Managed by the OS
 - Allocated in the TCB (e.g., `ld`)



Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12


15

Thread Control Block (TCB)

- `ld`
- Stack pointer
- Sleep counter
- Blocked pt (Lab 3)
- Priority (Lab 3)
- Next or Next/Previous links

Where are the registers saved?


```
struct TCB {
    // order??. types??
};
typedef struct TCB TCBType;
typedef TCBType * TCBPtr;
```



Look at TCB of uC/OS-II, `struct os_tcb` in `Micrium\Software\uCOS-II\Source\ucos_ii.h`

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12



PendSV Thread Switch (1)

- PendSV handler
 - Give PendSV handler lowest priority
 - Prevent switching out background tasks
 - Use C code to find next thread

TCB of a running thread *TCB of a thread not running*

CortexM: R0-R14, PC, PSR, SP.

TCB of a running thread: stack pointer, TCB link, Id, stack area, local variables, return pointers.

TCB of a thread not running: stack pointer, TCB link, Id, stack area, R0-R14, PC, PSR, local variables, return pointers.

- Trigger PendSV


```

NVIC_INT_CTRL_R = 0x10000000;
            
```

Page 160 of tm4c123gh6pm.pdf


```

ContextSwitch
LDR R0, =NVIC_INT_CTRL
LDR R1, =NVIC_PENDSVSET
STR R1, [R0]
BX LR
            
```

PendSV Thread Switch (2)

- 1) Disable interrupts
- 2) Save registers R4 to R11 on the user stack
- 3) Save stack pointer into TCB
- 4) Choose next thread
- 5) Retrieve new stack pointer
- 6) Restore registers R4 to R11
- 7) Reenable interrupts
- 8) Return from interrupt

Run *Testmain1*
 -Show TCB chain
 -Show stacks
 -Explain switch



Micrium\Software\uCOS-III\Ports\ARM-Cortex-M3\Generic\RealView\os_cpu_a.asm

Lecture 3

J. Valvano, A. Gerstlauer
 EE445M/ECE380L.12

19

Assembly Thread Switch

```

PendSV_Handler          ; 1) Saves R0-R3,R12,LR,PC,PSR
  CPSID I                ; 2) Make atomic
  PUSH {R4-R11}          ; 3) Save remaining regs r4-11
  LDR R0, =RunPt         ; 4) R0=pointer to RunPt, old
  LDR R1, [R0]           ; R1 = RunPt
  STR SP, [R1]           ; 5) Save SP into TCB
  LDR R1, [R1,#4]        ; 6) R1 = RunPt->next
  STR R1, [R0]           ; RunPt = R1
  LDR SP, [R1]           ; 7) new thread SP; SP=RunPt->sp;
  POP {R4-R11}          ; 8) restore regs r4-11
  CPSIE I                ; 9) tasks run enabled
  BX LR                 ; 10) restore R0-R3,R12,LR,PC,PSR
  
```

Program 4.9

RTOS_4C123.zip

Lecture 3

J. Valvano, A. Gerstlauer
 EE445M/ECE380L.12

20

Thread Management

- TCB
- Stacks
- Scheduler

See [Testmain1](#)

See [Testmain2](#)

Reference book, chapter 4

Lecture 3
J. Valvano, A. Gerstlauer
EE445M/ECE380L.12
21

Thread States

```

    graph TD
      dead((dead)) -- OS_AddThread --> active((active))
      run((run)) -- calls OS_Suspend --> active
      run -- "time slice is over, OS takes control away" --> active
      active -- "OS grants control" --> run
      run -- "calls OS_Sleep" --> sleep((sleep))
      sleep -- "time over" --> active
      run -- "calls OS_Kill" --> dead
  
```

Lab 3 will add Blocked

Lecture 3
J. Valvano, A. Gerstlauer
EE445M/ECE380L.12
22

Thread Scheduler

- When to invoke
 - Cooperative: `OS_Suspend()`
 - Preemptive: `SysTick`
- What **Active** task to **Run**
 - Round robin (Lab 2)
 - Weighted round robin
 - Priority (Lab 3)

Lecture 3


J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

23

Round Robin Scheduler

```
OS_AddThread(&Interpreter);
OS_AddThread(&Consumer);
OS_AddThread(&Math);
OS_Launch(TIMESLICE); // doesn't return
```

RunPt



Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

24

ARM Modes and Levels

Thread mode Used to execute application software. The processor enters Thread mode when it comes out of reset.

Handler mode Used to handle exceptions. The processor returns to Thread mode when it has finished exception processing.

The *privilege levels* for software execution are:

Unprivileged The software:

- Has limited access to the MSR and MRS instructions, and cannot use the CPS instruction
- Cannot access the system timer, NVIC, or system control block
- Might have restricted access to memory or peripherals.

Unprivileged software executes at the unprivileged level.

Privileged The software can use all the instructions and has access to all resources.

Privileged software executes at the privileged level.

Lecture 3
J. Valvano, A. Gerstlauer
EE445M/ECE380L.12
25

ARM Registers (1)

Open debugger to see these registers

Thread mode
- Main stack (MSP)
- Process stack (PSP)
Handler mode
- Main stack (MSP)

MRS Rx, <special>
MSR <special>, Rx

Lecture 3
J. Valvano, A. Gerstlauer
EE445M/ECE380L.12
26

ARM Registers (2)

General-purpose registers

R0-R12 are 32-bit general-purpose registers for data operations.

AAPCS:
R0-R3 parameters/return
R4-R11 must be saved

Stack pointer

The *Stack Pointer* (SP) is register R13. In Thread mode, bit[1] of the CONTROL register indicates the stack pointer to use:

- 0 = *Main Stack Pointer* (MSP). This is the reset value. **Which SP is active?**
- 1 = *Process Stack Pointer* (PSP).

On reset, the processor loads the MSP with the value from address 0x00000000.

Link register

R14 is important

The *Link Register* (LR) is register R14. It stores the return information for subroutines, function calls, and exceptions. On reset, the processor loads the LR value 0xFFFFFFFF.

Program counter

The *Program Counter* (PC) is register R15. It contains the current program address. Bit[0] is always 0 because instruction fetches must be halfword aligned. On reset, the processor loads the PC with the value of the reset vector, which is at address 0x00000004.

Lecture 3

J. Valvano, A. Gerstlauer
 EE445M/ECE380L.12

27

CONTROL Register

Figure 8. CONTROL bit assignments




Table 10. CONTROL register bit definitions

Bits	Function
Bits 31:2	Reserved
Bit 1	ASPSEL: Active stack pointer selection Selects the current stack: 0: MSP is the current stack pointer 1: PSP is the current stack pointer. In Handler mode this bit reads as zero and ignores writes.
Bit 0	TPL: Thread mode privilege level Defines the Thread mode privilege level. 0: Privileged 1: Unprivileged.

Reset debugger:
 - look at CONTROL
 - stop in ISR and
 - look at CONTROL

Lecture 3

J. Valvano, A. Gerstlauer
 EE445M/ECE380L.12

28

Exception Processing

Exception number	IRQ number	Offset	Vector
83	67	0x014C	IRQ67
.	.	.	.
.	.	.	.
18	2	0x004C	IRQ2
17	1	0x0048	IRQ1
16	0	0x0044	IRQ0
15	-1	0x0040	Systick
14	-2	0x003C	PendSV
13		0x0038	Reserved
12			Reserved for Debug
11	-5	0x002C	SVCall
10			Reserved
9			Reserved
8			Reserved
7			Reserved
6	-10	0x0018	Usage fault
5	-11	0x0014	Bus fault
4	-12	0x0010	Memory management fault
3	-13	0x000C	Hard fault
2	-14	0x0008	NMI
1		0x0004	Reset
		0x0000	Initial SP value

Remember -
Systick is 15

Stacking

Define

Group priority 0-15

Subpriority

Nested exceptions

Tail chaining

Late arrival

Return

Stack (8 regs):

- R0-R3, R12
- LR
- Return address
- PSR

LR=EXC_RETURN

0b11110001 Ret to Handler MSP

0b11111001 Ret to Thread MSP

0b11111101 Ret to Thread PSP

0b1110xxxx means floating point

aligned to double-word address

Run debugger:

- stop in ISR and
- look at LR
- draw stack frame

Program Status Register (PSR)

Figure 3. APSR, IPSR and EPSR bit assignments

Q = saturation





Figure 4. PSR bit assignments

T = Thumb bit



Interrupt Program Status Register (IPSR)

Bits	Description
Bits 31:9	Reserved
Bits 8:0	ISR_NUMBER: This is the number of the current exception: 0: Thread mode 1: Reserved 2: NMI 3: Hard fault 4: Memory management fault 5: Bus fault 6: Usage fault 7: Reserved 10: Reserved 11: SVCall 12: Reserved for Debug 13: Reserved 14: PendSV 15: SysTick 16: IRQ0 ⁽¹⁾

Run debugger:
- stop in ISR and
- look at IPSR

Figure 2-3, The IPSR Register.

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

31

Execution Program Status Register (EPSR)

The Execution PSR (**EPSR**) contains two overlapping fields:

- the Interruptible-Continuable Instruction (ICI) field for interrupted load multiple and store multiple instructions PUSH {r4-r6,lr}
- the execution state field for the If-Then (IT) instruction, and the T-bit (Thumb state bit).




Figure 2-4, The EPSR Register.

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

32

Priority Mask Register

Priority mask register

The PRIMASK register prevents activation of all exceptions with configurable priority. See the register summary in *Table 2 on page 13* for its attributes. *Figure 5* shows the bit assignments.

Figure 5. PRIMASK bit assignments



Table 7. PRIMASK register bit definitions

Bits	Description
Bits 31:1	Reserved
Bit 0	PRIMASK: 0: No effect 1: Prevents the activation of all exceptions with configurable priority.

DisableInterrupts (I=1)

CPSID I

EnableInterrupts (I=0)

CPSIE I

StartCritical():

MRS R0, PRIMASK
CPSID I

EndCritical():

MRS PRIMASK,R0

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

Code from uC/OS-II

```
SRSave
MRS    R0, PRIMASK
CPSID  I
BX     LR
SRRestore
MSR    PRIMASK, R0
BX     LR
```

```
// Prototypes :
long SRSave (void);
void SRRestore(long sr);
```

Where is the I bit saved?

```
#define OS_ENTERCRITICAL() { sr = SRSave(); }
#define OS_EXITCRITICAL() { SRRestore(sr); }

void Task (void *p_arg) {
    long sr=0;
    OS_CRITICALENTER();
    // ... critical section
    OS_CRITICALEXIT();
}
```

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

34

Exceptions

Exception number ⁽¹⁾	IRQ number ⁽¹⁾	Exception type	Priority	Vector address or offset ⁽²⁾	Activation
1	-	Reset	-3, the highest	0x00000004	Asynchronous
2	-14	NMI	-2	0x00000008	Asynchronous
3	-13	Hard fault	-1	0x0000000C	-
4	-12	Memory management fault	Configurable ⁽³⁾	0x00000010	Synchronous
5	-11	Bus fault	Configurable ⁽³⁾	0x00000014	Synchronous when precise, asynchronous when imprecise
6	-10	Usage fault	Configurable ⁽³⁾	0x00000018	Synchronous
7-10	-	-	-	Reserved	-
11	-5	SVCcall	Configurable ⁽³⁾	0x0000002C	Synchronous
12-13	-	-	-	Reserved	-
14	-2	PendSV	Configurable ⁽³⁾	0x00000038	Asynchronous
15	-1	SysTick	Configurable ⁽³⁾	0x0000003C	Asynchronous
16-83	0-67	Interrupt (IRQ)	Configurable ⁽⁴⁾	0x00000040 and above ⁽⁵⁾	Asynchronous

Table 2-8, Exception Types (TM4C123GH6PM Data Sheet)

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

35

Supervisor Call (svc)

3.9.10 SVC

Supervisor Call.

Syntax

```
SVC {cond} #imm
```

where:

- 'cond' is an optional condition code, see [Conditional execution on page 56](#).
- 'imm' is an expression evaluating to an integer in the range 0-255 (8-bit value).

Operation

The SVC instruction causes the SVC exception.

imm is ignored by the processor. If required, it can be retrieved by the exception handler to determine what service is being requested.

Condition flags

This instruction does not change the flags.

Examples

```
SVC 0x32 ; Supervisor Call (SVC handler can extract the immediate value
; by locating it via the stacked PC)
```

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

36

Decisions

- PendSV/SysTick or SysTick only?
 - Everything in one handler?
 - How to handle sleep and time keeping?
- Privileged/Unprivileged?
 - Trap or regular function call?
 - How do you link OS to user code?
- MSP/PSP or MSP?
 - Protection versus speed?
 - Check for stack overflow
 - Check for valid parameters


Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

37

Thread Switch with PSP (1)

- Bottom 8 bits of LR
 - 0xE1 11110001 Return to Handler mode MSP (using floating point state)
 - 0xE9 11101001 Return to Thread mode MSP (using floating point state)
 - 0xED 11101101 Return to Thread mode PSP (using floating point state)
 - 0xF1 11110001 Return to Handler mode MSP
 - 0xF9 11111001 Return to Thread mode MSP
 - **0xFD 11111101 Return to Thread mode PSP**



Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

38

Thread Switch with PSP (2)

```

; This code uses MSP for user and OS (Program 4.9 from book)
SysTick_Handler          ; 1) Saves R0-R3,R12,LR,PC,PSR
  CPSID    I              ; 2) Prevent interrupt during switch
  PUSH     {R4-R11}       ; 3) Save remaining regs r4-11
  LDR      R0, =RunPt     ; 4) R0=pointer to RunPt, old thread
  LDR      R1, [R0]        ;   R1 = RunPt
  STR      SP, [R1]        ; 5) Save SP into TCB
  LDR      R1, [R1,#4]    ; 6) R1 = RunPt->next
  STR      R1, [R0]        ;   RunPt = R1
  LDR      SP, [R1]        ; 7) new thread SP; SP = RunPt->sp;
  POP      {R4-R11}       ; 8) restore regs r4-11
  CPSIE    I              ; 9) run with interrupts enabled
  BX       LR              ; 10) restore R0-R3,R12,LR,PC,PSR

```

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

39

Thread Switch with PSP (3)

```

; tasks use PSP, OS/ISR use MSP, Micrium OS-II
SysTick_Handler          ; 1) R0-R3,R12,LR,PC,PSR on PSP
  CPSID    I              ; 2) Prevent interrupt during switch
  MRS      R2, PSP         ; R2=PSP, the process stack pointer
  SUBS     R2, R2, #0x20
  STM      R2, {R4-R11}    ; 3) Save remaining regs r4-11
  LDR      R0, =RunPt     ; 4) R0=pointer to RunPt, old thread
  LDR      R1, [R0]        ;   R1 = RunPt
  STR      R2, [R1]        ; 5) Save PSP into TCB
  LDR      R1, [R1,#4]    ; 6) R1 = RunPt->next
  STR      R1, [R0]        ;   RunPt = R1
  LDR      R2, [R1]        ; 7) new thread PSP in R2
  LDM      R2, {R4-R11}    ; 8) restore regs r4-11
  ADDS     R2, R2, #0x20
  MSR      PSP, R2         ; Load PSP with new process SP
  ORR      LR, LR, #0x04  ; 0xFFFFFFF0 (return to thread PSP)
  CPSIE    I              ; 9) run with interrupts enabled
  BX       LR              ; 10) restore R0-R3,R12,LR,PC,PSR

```

Lecture 3

OS calls implemented with trap (SVC)

40

Code from uC/OS-II

```

NVIC_PENDSVSET EQU 0x10000000
NVIC_INT_CTRL EQU 0xE00ED04

```

```

OSCtxSw
LDR R0, =NVIC_INT_CTRL
LDR R1, =NVIC_PENDSVSET
STR R1, [R0]
BX LR

```

```
#define OS_TASK_SW() OScTxSw()
```

```

OS_CPU_PendSVHandler
CPSID I ; Prevent interruption during context switch
MRS R0, PSP ; PSP is process stack pointer
; ....
MSR PSP, R0 ; Load PSP with new process SP
ORR LR, LR, #0x04 ; exception return uses process stack
CPSIE I ; not necessary, PSR will be popped
BX LR

```

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

41

NVIC

- Set priorities
 - PendSV low
 - Timer1 high
- Trigger PendSV

```

NVIC_INT_CTRL_R
Page 160 of tm4c123gh6pm.pdf

```

Launch

- Set SysTick period
- Set PendSV priority
- Using RunPt
 - Pop initialize Reg
- Enable interrupts
- Branch to user

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

42

To do first (1)

- Debugging
- Interrupts
- OS_AddThread
- Assembly
- NVIC
- PendSV
- OS_Suspend
- OS_Launch

To do last (2)

- Stack size
- FIFO size
- SysTick period
- PSP
 - Just use MSP
- OS_Sleep
- OS_Kill
- Semaphores

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

43

Lab 2 Part 1 (1)

- Debugging
 - How to breakpoint, run to, dump, heartbeat
- Interrupts
 - How to arm, acknowledge, set vectors
 - What does the stack look like? What is in LR?
- OS_AddThread
 - Static allocation of TCBs and Stack
 - Execute 1,2,3 times and look at TCBs and Stack
- Assembly
 - PendSV, push/pull registers, load and store SP
 - Enable, disable interrupts
 - Access global variables like RunPt

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

44

Lab 2 Part 1 (2)

- NVIC
 - Arm/disarm, priority
- PendSV
 - How to trigger
 - Write a PendSV handler to switch tasks
- OS_Suspend (scheduler and PendSV)
- OS_Launch (*this is hard*)
 - Run to a line at the beginning of the thread
 - Make sure TCB and stack are correct


Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

45

Debugging tips

- Visualize the stacks
- Dumps and logs
- Logic analyzer




Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

46

Aperiodic Tasks (1)




- Switch debouncing
 - Assume a minimum touch time 500ms
 - Assume a maximum bounce time 10ms
- On touch
 - Signal user, call user function (no latency)
 - Disarm. **AddThread(&BounceWait)**
- BounceWait
 - Sleep for more than 10, less than 500 ms
 - Rearm. **OS_Kill()**

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

47

Aperiodic Tasks (2)



- Switch debouncing
 - Assume a maximum bounce time 10ms
- Interrupt on both rise and fall
 - If it is a rise, signal touch event
 - If it is a fall, signal release event
 - Disarm. **AddThread(&DebounceTask)**
- DebounceTask
 - Sleep for 10 ms. **OS_Sleep(10)**
 - Rearm, Set a global with the input pin value
 - **OS_Kill()**

Define latency for this interface

Lecture 3

J. Valvano, A. Gerstlauer
EE445M/ECE380L.12

48


Switch Debounce

```

void static DebounceTask(void) {
    OS_Sleep(10); // foreground sleeping, must run within 50ms
    LastPD6 = PD6; // read while it is not bouncing
    GPIO_PORTD_ICR_R = 0x40; // clear flag6
    GPIO_PORTD_IM_R |= 0x40; // enable interrupt on PD6
    OS_Kill();
}
void GPIOPortD_Handler(void){
    if(LastPD6 == 0) // if previous was low, this is rising edge
        (*PD6Task)(); // execute user task
    GPIO_PORTD_IM_R &= ~0x40; // disarm interrupt on PD6
    OS_AddThread(&DebounceTask);
}

```

Quiz 1, Question 9,
Spring 2012



Summary

- Threads are executing software tasks
- RTOS has unique requirements
 - Reliability
 - Real-Time
 - Priority
 - Certification
 - Runs in ROM